


Mini programmer / modulator operating instructions



1. 'P' Key (-)
2. 'HEAT' Key (+)
3. Decrease Temperature Key
4. Increase Temperature Key
5. Pre-Set Symbol
6. Disengaged Pre-Set Symbol
7. Clock Symbol
8. Day Selected Indicator Box
9. Current Time, Pre-Set Time and Heating Time
10. Heater Operation Symbol
11. Temperature Scale

Setting the time of day

- A. Whenever power is applied to the programmer the display will flash **88:88** repeatedly.
- B. To set the time, press **-P** **HEAT** keys at the same time until the flashing clock symbol **⌚** appears. Use **-P** and **HEAT** keys to set the time of day. Once the correct time of day is displayed the flashing clock symbol will remain active for a further 6 seconds after which the displayed time will be set.
- C. When the time of day setting has been completed the box symbol **☐** will start flashing. Use **-P** and **HEAT** keys to set the day of the week. Once the correct day is displayed the flashing box symbol will remain active for a further 6 seconds after which the displayed day will be set.
- D. When the box symbol **☐** stops flashing press the **HEAT** key. The time and day setting is now completed.
- E. If the time or day is set incorrectly, or requires adjustment, repeat the above procedure.
- B. With **P** symbol showing on the programmer display, press and hold **HEAT** key until the pre-set symbol P1 starts to flash.
- C. While P1 is still flashing use **-P** and **HEAT** keys to set your first pre-set 'ON' time.
- D. Wait until P2 starts to flash and set your second pre-set 'ON' time. If this is not required, set P2 to 00:00, the timer will display **OFF**.
- E. Wait until P3 starts to flash and set your third pre-set 'ON' time. If this is not required, set P3 to 00:00 the timer will display **OFF**.
- F. P1P2P3 will start to flash on the programmer screen. The active days can now be set.
- G. While P1P2P3 are still flashing, adjust the days you want P1P2P3 to operate.
- H. Use **HEAT** key to select **on** or **OFF** for the day indicated in the day box. Use **-P** key to advance to the next day.
- I. Repeat until all day settings are complete.

To switch on the heater

Press the **HEAT** key and the heat symbol **☼** will appear on the programmer screen. The heater is now switched on.

To switch off the heater

Press the **HEAT** key and the **☼** symbol will disappear. The heater will now commence its shut down cycle of approximately 3-4 minutes.

To adjust the desired temperature level

Note: The temperature setting on the modulator can only be adjusted while the heater is switched on via the programmer.

To change the heater temperature, press and hold the **-** or **+** accordingly, after a 2 second delay the temperature scale **☺** will increase or decrease as desired. As a guide, the temperature scale **☺** is adjustable between 10°C and 30°C

To set pre-set switch on/off times

- A. The programmer has 3 adjustable on/off times which can be set to activate on different days of the week.
The maximum duration of any one pre-set is 60 minutes.

To activate pre-set times

- A. Press **-P** key, the screen display will change from **P** to P1P2P3
- B. The programmer will now automatically switch the heater on as set until the pre-set times are deactivated.

To deactivate pre-set times.

Press **-P** key the screen display will change from P1P2P3 to **P**

Display settings

The timer has a back-lit display that illuminates when any of the timer buttons are pressed (recommended setting), however by depressing the **-P** for 6 seconds the illumination can be set on permanently, timer displays **on** the timer can be set back to normal mode by pressing **-P** for a further 6 seconds, timer displays **OFF**.